

How to enter my Unlock Code on SonyEricsson ?

Model : All SonyEricsson

- 1 - Switch ON your phone without SIM Card,
- 2 - Press 1 time the left arrow,
- 3 - Press 2 times the button * ,
- 4 - Press 1 time the left arrow,
- 5 - The message "Personalize with MNC2" will appear,
- 6 - You can now enter the Unlock Code we send to you.

If your phone have a "JOGDIAL" (ex : SonyEricsson K700i) you must press "down arrow" instead of "left arrow" for step 2 & 3. We mean by "Down Arrow" to direct the Jogdial down !